

Road Service Quick Reference Guide
2016 Lincoln MKT



Quality and Education Services
AAA Automotive
1000 AAA Drive
Heathrow, FL 32746

December 12, 2015

Index

Towing, Loading and Transporting	2
Curb Weight	2
Car Carrier Loading	3
Neutral Mode	4
Shift Lock Override Procedure	4
Jacking and Tire Service	5
Fuel Service	7
Jump-Start Procedures	8
Electronic Key	9
Hood Release	11

Important Notice:

This publication should not be used while driving. The procedures in this publication should only be used by qualified and trained personnel.

This Road Service Quick Reference Guide was developed to highlight some common procedures when servicing or towing a Lincoln vehicle. It is not all inclusive. For complete information: the applicable vehicles owner's manual, Ford Wrecker Towing Manual and the AAA Towing and Service Manual should be used in conjunction with this guide.

The procedures recommended and described in this guide are effective methods of performing light service and towing operations. Some of these procedures require the use of auxiliary equipment specially designed for the purpose. The auxiliary equipment should be used when and as recommended and whenever the trained operator deems it appropriate. It is important to read the various WARNINGS, CAUTIONS and NOTES in this manual in order to minimize the risk of personal injury to service personnel and or customers and to avoid procedures which may damage the vehicle or render it unsafe. It is also important to understand that these warnings, cautions and notes are not exhaustive. Neither AAA nor the auto and towing equipment manufacturers could possibly know, evaluate and advise the reader of all conceivable methods of towing or evaluate individual situations. Accordingly, anyone who uses a towing procedure must be thoroughly convinced that neither personal safety nor vehicle safety will be jeopardized by the selected procedure.

AAA is not responsible for changes made by the manufacturers to the vehicles or their recommendations. Important changes in procedures will be furnished to all manual users on the internet at AAA.biz/auto.

TOWING, LOADING AND TRANSPORTING:


Base Curb Weight

MKT -FWD: 4702 lbs.


MKT -AWD: 4,942 lbs.

Correct towing equipment for specific models:


The use of car carrier equipment is the preferred method of towing all Lincoln vehicles. A secondary, alternative wheel lift with dollies procedure may be used when a car carrier is inaccessible.



Car Carrier is the Recommended Towing Procedure for: All Lincoln vehicles



Secondary, Alternative Procedure: Wheel lift with Dollies: AWD, FWD, Front Wheel Lift and Rear Wheel Lift



Ford Motor Company has not approved a slingbelt towing procedure. Vehicle damage may occur if towed incorrectly, or by any other means.

CAR CARRIER LOADING:



Front T-Slot



Nylon Bridal with Short Nylon Strap Extension

Use the front two reinforced T-slots to load the vehicle onto a car carrier. The use of a nylon bridle with a secondary nylon strap will assist in avoiding damage to the under panel splash shields. Before loading, ensure that the transmission is in “Neutral”.

Securing the Vehicle for Transport

Note: Wheel Straps should be used to secure the vehicle for transport. A secondary method is securing by using the reinforced T-hook slots.

When the vehicle is in its loaded position on the flatbed with the bed still in the deployed position, secure the vehicle to prevent it from rolling by chocking the wheels and attaching one wheel strap or tie down to the wheel closest to you, then set the parking brake.

Caution: Do not overly tighten the tie downs or the vehicle may be damaged.

After securing, return the bed to the transporting position, then slacken the winch wire rope slightly to prevent downward pull as bumps are encountered during transport.


Note: Make sure that the ignition switch is in the OFF position, the vehicle is in Park and parking brake is set.

BRAKE-SHIFT INTERLOCK OVERRIDE:

Use the brake-shift interlock override to move the transmission from the Park position in the event of a malfunction.

Caution: Prior to performing this procedure secure the vehicle and ensure it will not roll. Deploy wheel chocks if needed.

1. Apply the parking brake and turn the ignition off before performing this procedure.



2. Carefully remove the access plug on the side of the center console.
3. Apply the brake pedal. Using a suitable tool (for example, a screwdriver), push the brake-shift interlock override lever forward while pulling the gearshift lever out of Park (P) and into Neutral (N).
4. Install the access plug on the side of the center console.
5. Apply the brake pedal, start the vehicle, and release the parking brake.

JACKING AND TIRE SERVICE:



This model may be equipped with an inflator kit. Lincoln requires that models without a spare tire be towed. **Do not** deploy the inflator kit if equipped.

Spare Tire Change Procedure -When Equipped

Note: Check the tires and set the parking brake to ensure the vehicle will not move.




The spare tire and factory tools are located in the rear cargo area under the package shelf, in the wheel well.




Use the jacking points shown above. Place the jack in its proper location. Observe all standard jacking precautions and ensure that the vehicle is on firm, level ground and that the wheels are chocked. As the jack comes in contact with the vehicle body, ensure that it is contacting the correct location on the vehicle.

Stowing the flat tire:



If the road wheel you removed cannot be secured in the wheel well area, remove the L-shaped bolt from the external pocket of the felt bag. With the third row seat in the raised position, stand the flat tire in the rear of the vehicle with the tire's valve stem facing the rear of the vehicle. Fasten the flat tire to the vehicle by inserting the L-shaped bolt through one of the lug bolt holes in the wheel. Turn it clockwise into the threaded hole in the vehicle until the tire is secured.



Tighten lugnuts in the pattern shown above

Wheel Lug Nut Torque Specifications

When a wheel is installed, always remove any corrosion, dirt or foreign materials present on the mounting surfaces of the wheel or the surface of the wheel hub, brake drum or brake disc that contacts the wheel. Make sure that any fasteners that attach the rotor to the hub are secured so they do not interfere with the mounting surfaces of the wheel. Installing wheels without correct metal-to-metal contact at the wheel mounting surfaces can cause the wheel nuts to loosen and the wheel to come off while the vehicle is in motion, resulting in loss of control.

Bolt size	lb.ft (Nm)
1/2 x 20	100 lb.ft (135 Nm)
M14 x 1.5 (Limousine only)	150 lb.ft (204 Nm)

*Torque specifications are for nut and bolt threads free of dirt and rust. Retighten the lug nuts to the specified torque as soon as possible and no more than 100 miles (160 kilometers) after changing a flat tire.

WARNING: Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.

- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.
- When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
- Check for any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel.
- Never install a wheel with excessive rust. Light surface rust should be cleaned off of the wheel and mounting surface.
- Never install a tire with excessive tread wear.

FUEL SERVICE:



Locate the portable funnel that comes with the vehicle. The fuel filler funnel is located in the spare wheel storage tray. Carefully insert the funnel into the capless fuel system to add fuel.

Note: Lincoln recommends adding a minimum of 1.3 gal of fuel to restart the engine. If the vehicle is out of fuel and on a steep slope, more fuel may be required.

FUEL SHUTOFF:

In the event of a moderate to severe collision, this vehicle includes a fuel pump shutoff feature that stops the flow of fuel to the engine. Not every impact will cause a shutoff.

Should the vehicle shut off after a collision, you may restart the vehicle. For vehicles equipped with a key system:

1. Switch off the ignition.
2. Switch on the ignition.
3. Repeat steps 1 and 2 to re-enable the fuel pump.

For vehicles equipped with a push button start system:

1. Press the START/STOP button to switch off the ignition.
2. Press the brake pedal and press the START/STOP button to switch on the ignition.
3. Remove your foot from the brake pedal and press the START/STOP button to switch off the ignition.
4. You can either attempt to start the engine by pressing the brake pedal and the START/STOP button, or switch on the ignition only by pressing the START/STOP button without pressing the brake pedal. Both ways re-enable the fuel system.

JUMP-STARTING:

The battery is located on the driver's side of the engine compartment.



Ground Location

- Follow all normal jump-starting precautions as outlined in other AAA/CAA publications and those provided by the manufacturer.
- Ensure that all electrical accessories and the ignition switch are turned OFF and the ignition key is removed from the ignition before connecting jumper cables or a jumper box to the discharged vehicle

ELECTRONIC KEY:




The intelligent access keys operate the power locks and the remote start system. The key must be in the vehicle to activate the push-button start system.



Removable Key Blade: The intelligent access key also contains a removable mechanical key blade that you can use to lock or unlock the driver door.

If the key is not detected try the following:

1. Open the floor console storage compartment lid.



2. Insert the passive key into the backup slot.

3. With the passive key in this position, you can use the push button ignition switch to switch the ignition on and start the vehicle.

Changing Batteries in the Intelligent Access Transmitter

Note: Replacing the battery will not delete the transmitter from the vehicle. The transmitter should operate normally. The remote control uses one coin-type three-volt lithium batteries CR2032 or equivalent.



1. Remove the key blade from the transmitter.
2. Twist a thin coin under the tab hidden behind the key blade head to remove the battery cover. Do not use the key blade to remove the cover or you could damage it.



3. Remove the old battery.
4. Install new battery with the + facing downward. Press the battery down to make sure it is fully in the housing.
5. Reinstall the battery housing cover onto the transmitter and install the key blade.

HOOD RELEASE:



To open the hood: pull the hood release handle located under the far left-hand side of the instrument panel.